

Simple Installation

Takes only seconds to prepare your server.

Installing the PVI-Server Software

Installation for the Pointmaker PVI-Server software prepares your server to handle the Multipoint features.

- 1) Insert the PVI-Server Software CD into the appropriate drive.
- 2) Click the START icon in the Windows tool bar, and select RUN.
- 3) Type in the drive letter and a colon followed by "\setup.exe" (e.g., D:\setup.exe).
- 4) Select OK.
The PVI-Server software will be installed.
- 5) When installation is complete, click OK to close installation.

...or Use Our Server



Set the **Server IP** to
67.19.240.122

and we will be glad to serve your meetings.

Network Configuration

Minimal entries for activation.

| MULTIPOINT NETWORK | |
|--------------------|---------------|
| SERVER IP | 10.0.1.204 |
| SERVER PORT | 10001 |
| | DHCP |
| | STATIC |
| IP ADDRESS | 10.0.1.146 |
| NETMASK | 255.255.255.0 |
| GATEWAY | 10.0.1.128 |
| | INIT DEVICE |
| | PREVIOUS MENU |

Enter SERVER IP and SERVER PORT.

Select DHCP or STATIC.

If DHCP is selected, IP ADDRESS, NETMASK and GATEWAY are assigned automatically.

If STATIC is selected, you must make entries for IP ADDRESS, NETMASK and GATEWAY.

Select INIT DEVICE to finish the network configuration.

The system is up and running, ready for your users to create and join their Multipoint meetings.

Easily Create and Join Meetings

Three short steps.

| MULTIPOINT CONNECT | |
|--------------------|--|
| NAME | |
| MED GROUP 9 | |
| PASSWORD | |
| ***** | |
| CREATE NEW | |
| JOIN CURRENT | |
| EXIT MEETING | |
| PREVIOUS MENU | |

Create a New Meeting

- 1) Enter the NAME of the meeting and the PASSWORD you wish to assign.
- 2) Select CREATE NEW.
Notify attendees of the name and password so they can join the meeting. They can then join your meeting...

Join a Meeting

- 1) Enter the NAME of the meeting and the PASSWORD.
- 2) Select JOIN CURRENT.
The server handles all connections. After you exit the menu system, you can now interactively mark over any displayed images.



www.pointmaker.com


Boeckeler Instruments, Inc. • 4650 South Butterfield Drive • Tucson, AZ • 85714 • U.S.A.

Phone (520) 745-0001 • **Fax** (520) 745-0004 • **E-Mail** info@boeckeler.com


© 2005 Boeckeler Instruments, Inc. *Pointmaker* and *Boeckeler* are registered trademarks of Boeckeler Instruments, Inc., Tucson, Arizona.
All other trademarks are the property of their respective owners. All specifications subject to change without notice.

multipoint flyer.indd/RE

Data Connections for Sharing Annotation Commands



Video Flow Diagram for Videoconferencing Setup




MULTIPOINT

Collaborative annotation over **LAN** or **Internet** becomes a reality with the MULTIPOINT system for Pointmaker® Video Markers, by adding annotation to your existing videoconference system. Now, two or more people can interactively mark over shared video images, bringing a Pointmaker focus to meetings, whether participants are a floor, a city, or a country away.

- Focus Attention Exactly
- Far End Participants Annotate Over Near End Video
- 2 or More Locations Connected Over LAN or Internet

Over LAN . . .



or Internet . . .

